User manual for the measuring program ic.exe (ISee!)

This software allows the computer-aided analysis of digital radiographs via measurements of profiles, wall thickness differences and local corrosions, the storage of results and statistical evaluation of image regions (by mean value, standard deviation and normalized signal-to-noise ratio). It is developed at BAM Berlin to promote new applications of Digital Industrial Radiology (DIR) and as a vendor-independent program to realize measurements defined in various CEN, ISO and ASTM standards for Non-destructive testing (NDT) with radiological methods.

Two versions are available:

1) The version *IC.exe*
   This is the full version, which requires a software license. After starting the program on a computer without a license, you will be prompted with a binary code, which you shall email to uwez@bam.de to get your proper software license. The license key you will then get send back is specific to the PC and is just valid on this computer. Because it is stored in the registry and therefore is specific to the user, it might be necessary to install the same license key separately for each user of multi user systems (WinXX). To obtain a license key the signature of a license contract and a fee of 500 Euros per license is required.

2) The demo version *IC-demo.exe*
   This version does not require a license; however it is not possible to save any data. It is freely available and can be handed on to customers, to make the data analysis traceable (e.g. it can be saved on the data-CD, to get an easy access to the data).

Digital images up to a resolution of 16 bit in gray value with arbitrary size and different formats can be loaded in the measuring program. The following file formats are supported (the list of implemented formats depends on the ISee! Version). Newer versions support formats like the AGFA RADView format *.lmg, DICOM *.xml data or the DICOM/DICONDE *.dcm standard format, Duerr *.xyz images or PNG images *.png):



How to run „ISee!“ (ic.exe)

Simply by clicking on the program icon:



There is no installation required, Just start the exe file, that's all!

The digital image which is to be measured can be opened in two ways:

either using ***Open*** on the tool-bar, choosing the according directory and loading the image via double click

(see page 6)



or using ***File*** and ***Open from Recent Directory*** (a list which was created automatically when opening former digital images) and loading the image via double click.

Displays the 12 recently loaded directories

Displays the 12 recently loaded digital x-ray images or datasets



The chosen digital image is then going to be loaded and a window is opened, which gives information about the size and format of the image, the directory in which the image is stored and the speed of loading (in megabyte per seconds):


Action in progress
Loading 7040 x 8560 16 bpp TIFF
hantom_90kV_4mA_3min_1800mm_DynamIX_HR_UR-1_linear.tif
53.7 of 114.94 Mb (47%) at 6.2 Mb/sec
Interrupt

In this "*Action in progress*" window the loading can also be interrupted. Hence the image will not be loaded completely.

Only data retrieved until interruption will be displayed in the "*ISee!*" window. The remaining missing data-region of the image will be displayed in blue colour (which marks the data points with gray value of 0).



If the loading of the image - in this example a TIFF file - is not interrupted, the complete digital image file will be displayed in the "*ISee!*" window on the monitor:



To obtain a radiation dose proportional 16 bit display for the measurements a suitable Look-Up table (LUT) may loaded for the according image. The LUT is accessed either via the click of the button or using ***Image ➔ Load LUT***.
This operation does not change the raw data. If raw data transformed via LUT table should be stored, the menu point ***Image ➔ Transform throught the Current LUT*** has to be called, then the data were transformed according to the selected LUT and finally this LUT is disabled. Finally, the LUT transformed raw data can be saved (*see page 10).*



ⓘ Attention!
An LUT adjustment is necessary for many digital images and is dependent on device construction. Each scanner should be checked for its specific LUT to provide dose proportional gray values.

The following examples of digital images require the accordingly given LUT tables:

Digital images from	Look-up table (LUT) for negative display
CCD-Scanner VXR 16 by Vidar	LUT16bitcbrt.txt
CR- and CRx-Tower by GE IT	LUT12bitsquare16.txt
ACR-2000 Scanner by Kodak	LUT12bitdelog.txt
Laser–Scanner Array 2905 HD	**LUT12bitnegArrayHD.txt**

Indications at the status line of ISee! image window:



Indication of enlargement factor for monitor display of the image.
Also input of a different value is possible *(click with left mouse button and input directly e.g. 25%, 200% or 2.5).*

Indication of cursor position (x, y)-coordinates and gray value GV: after LUT transformation and (raw: gray value) before LUT transformation.

Indication of SNR (Signal-to-noise ratio) in vertical and horizontal direction.
The SNR is measured in a line of 20 pixels and as median of 55 lines (see EN 14784-1 for details), this window of 20x55 pixels is centred around the cursor position.
SNR display selection by right click on the status bar

Indication of loaded LUT for gray value transformation: original gray value → used LUT → gray value after LUT transformation (as shown after GV:).

Overview on functions of the main „*ISee!*“ *window*

The *ISee*! window displays the digital radiograph together with indications of evaluation created by the user. Roll-up menus, buttons and function keys call the same menus and lists in ISee!

Roll-up Menus of the ISee! window:

File menu



Open… ***Open from Recent Directory***	window with file selection in actual directory window with list of the 12 directories used recently) *(see page 2)*
Open Recent Dataset or Image	List of the 12 recently used image files (e.g. *.tif) or recently loaded data sets ***.ics**
Import Image	Select data source — Selection of a scanner from the list of the installed TWAIN data sources Acquire image — Opens TWAIN interface window for control of the selected TWAIN data source. (e.g. Laser scanner) The TWAIN interface supports 16 bit grey values. Colour images are converted to gray scale images by averaging.
Save Image As...	Storage of digital image files in the following image formats:  (MS-Windows BMP are files in 8 bit format) ➔ *Storage of image data in 8 bit converted through the actual LUT as displayed on the screen (e.g. for inclusion into reports or presentations)*
Save Dataset As...	Storage of data sets in ASCII format **(*.ics).** In these“***.ics**“ ASCII files all information is stored to repeat the evaluation later.
Exit	End of program

16bpp Greyscale TIFF (*.tif;*.tiff)
16bpp Greyscale TIFF (*.tif;*.tiff)
16bpp Greyscale TIFF with LZW compression (*.tif;
SunVision 16bpp Rasterfile (*.vff)
ScanManager 16bpp Image (*.im;*.dba)
RADView LMG (*.lmg)
MS-Windows BMP (discard Higher byte)
MS-Windows BMP (discard Lower byte)
MS-Windows BMP (as on screen)

View menu



Fit to screen	Full view, displays the complete image in the window
1:1 Zoom	Normal view, displays image **1:1**, i.e. 1 pixel at the display is exactly 1 pixel in the data file!
Zoom In	Displayed image is enlarged with every mouse click by a factor of $\sqrt{2}$.
Zoom Out	Displayed image is demagnified with every mouse click by a factor of $\sqrt{2}$.
Negative Representation	Displayed image in negative presentation (“film like”). The inverted monitor LUT is not shown.
Latitude Warning	Saturated image regions are marked by colour (blue colour: grey value = 0; red colour: grey value = 2^{NBits} -1).
Data to Screen Mapping Levers	An additional window is opened *(Histogram)*, in which an optimization could be done with the mouse by variation of the displayed brightness and contrast of the digital image on the monitor (see page 16 for details).
ROI List (Region of Interest)	***Opens additional window for managing the list of annotated objects***  ***to the image:*** - profiles - penetrameter values - statistics - annotating rectangles - annotating circles for measurement of round objects Delete annotation object Add annotation object Copy ROI list to Clipboard **Note:**

	Distance measurements are given in **„pixel“** numbers until image pixel calibration is done. To measure directly in **„mm“** a calibration value has to be provided via menu **Image > Input Pixelsize and SRb** (*see p. 14)*.  *(example: „ROI-List“ for profile measurement, see p. 24 - 27)* *(example: „ROI-List“ for statistics evaluation, see p. 28 and 29)*
Meta Info	Information about meta data in the file, which are provided additionally by a suitable header beside the raw image data inside the loaded file. See this example for TIFF tags in a TIFF file:  This window is especially usefully to access the TAGs defined in DICOM and DICONDE Files.

Image menu



Image ➔ *Adjust Pixels (Apply Calibration)*



A straight forward algorithm was implemented for correction of structure noise of the digital image. This dialogue asks for an ASCII text file describing the names of white field images (one file name per line). These flat field images are ordered with increasing pixel intensities starting with the black image (no X-ray dosage) in the first line. A pixel wise linear interpolation for gray values of the loaded image between the flat field images is used (see file “pixel_calibration_demo.zip” containing example data and further documentation). An algorithm for interpolation of bad pixels is implemented too.

Image ➔ *Pixel Arithmetics*


Pixel Arithmetics
Calculations will be made solely on pixel-per-pixel basis (without any spatial relations between pixels). First operand is always the current image (which you see now). Please select an operation and specify the second operand. If necessary, use scaling and offset addition from the normalization section of this dialog in order to get the result fitting in unsigned 16-bit integers (ISee! internal representation).
Operation:
2nd operand:
set
add
substract
multiply
divide
min
max
difference
Scalar:
Image (same dimensions as the current one):
X:\projects\IAEA\DIR2009\Phantom Ir
...
Zero-mean normally distributed random value with standard deviation
Normalization:
Scale
1,0
Offset
10000,0
Remember as default
Cancel
Ok

This windows allows simple arithmetic with the loaded image. A scalar value can be used to modify each pixel of the displayed image, a second image (of course with identical size in x- and y- direction) can be combined pixel by pixel or white noise with a given standard deviation can be added to the image. The calculation is done in floating point; a scale and offset value can be applied finally before conversion to the unsigned 16 bit integer range used in ISee!

Image ➔ *Load LUT; Reset to Linear LUT; Transform through the Current LUT*

Load LUT	Loads a LUT table for correction of the 16 bit raw data (ASCII look up table (*.txt). The integer value of the first line in this ASCII file replaced gray value 0, the value on the second line gray value 1 etc. A 12 bit LUT should have 4096 Lines with one integer number per line.  *(see p. 4)*
Reset to Linear LUT	Disables any active LUT, original raw data are preserved.
Transform through the Current LUT	Corrects the original 16 bit raw data by transformation via selected LUT table and replaces all raw data by the transformed values. The used LUT is afterwards disabled. In this way LUT corrected raw data can be stored.

Image ➔ *Filter*

For improvement of the displayed image different filters are available. They allow contrast enhancement, noise suppression, edge enhancement, high- or low-pass filtering. For reduction of processing time only the image regions of interest should be filtered. The program filters only the complete image data, so a region of interest should be created by cropping the image size with the help of the **Image**-> **Geometry** ->**Crop** window before image filtering.



Enhance Details

A fast 2 dimensional FFT high pass filter without any parameter.

Optimum results for background suppression and enhancement of fine image details.

Extract Details

A fast 2 dimensional FFT high pass filter without any parameter. Optimum results for background suppression and enhancement of fine image details. Stronger than “Enhance details”



example: original Enhance Details Extract Details

Bessel FFT

Realizes a direction dependent 1 dimensional or a 2 dimensional FFT filter. By this high pass filtering e.g. horizontal or vertical crack indications can be enhanced. Any existing low frequency background will be suppressed.

As windowing function after FFT filtering a Bessel function is used. The Bessel filter width is provided in pixels in the original data. A high-pass with 7 pixels width suppresses all structures with a width larger than 7 pixels.

The value at „Scale result“ is multiplied with the filtered real data value to preserve very small values at the conversion to the integer gray values of the image data.







original with Bessel filter

Convolution…

After loading an suitable ASCII convolution kernel (*.txt) the raw image (**after** LUT-transformation) gets convolved with this kernel. The chosen kernel (of arbitrary size) governs the effect on the resulting image.



Running Mean...

Very fast recursive mean-filter of arbitrary size in 2 dimensions (i.e. processing time is independent of size of the filter kernel!).

Low-pass filter

Suppression of high frequencies, good suppression of noise, image becomes blurred.

Chose size of filter as small as possible. *rectangular window e.g. 5 X 5 pixels*

High-pass filter (with gray value offset):

Suppression of the low frequency background, image becomes noisier but a good display of the edges is achieved.

Chose size of filter as big as possible. *Rectangular window e.g. > 11 x 31 pixels or*



Raw data before filtering

Quadratic window > 51 x 51 pixels ***gv-offset:*** *approx. half of the max. bit dynamic* *e.g.: for 12 bit = 2000* *for 16 bit = 30000* **high-boost** image gets sharpened about x%. *(approx. 200% to 400%*, amplification of high frequency parts). A high pass filtered image is added to the raw data. **arbitray mask:** A mask file in ASCII can be loaded, which describes the filter size (non-rectangular kernel sizes for special applications are feasible in this way).	 
Running Median... Filter choice identical to *Mean*, with the exception of using the median value instead of the mean in the window X x Y.	**Attention!** **This filtering can take a lot of processing time, because a recursive implementation is not possible!**
Pseudo Plast ... Calculates the difference between the image and its copy, but shifted by the X shift and Y shift pixels. By subtracting two identical images, which are marginally shifted to each other the edges can be accented in a spatial orientation. In case of a horizontal shift the vertical edges are pronounced, contrariwise a vertical shift causes an accent of the horizontal edges. **GV offset:** Zero shift in the output image, approx. half of the bit-region	 
Remove Spots Special function to remove spots or lines with higher (or lower or both) intensity than the average image (e.g. background structures). Algorithm is still under development, information on parameter settings only available with example images.	
Erode (loe 5)	Erosion on a gray scale image, no documentation available yet, very special.
Dilate (goe 3)	Dilation on a gray scale image, no documentation available yet, very special.

Image ➔ Geometry



Rotate 180°	Image is rotated by 180°.
Rotate 90° CW	Image is rotated *clockwise (CW)* by 90°.
Rotate 90° CCW	Image is rotated *counter-clockwise (CCW)* by 90°.
Rotate arbitrary ...	Inactive *(arbitrary angles of rotation, not yet implemented)*
Flip Horizontal	Image is mirrored along the vertical middle axis.
Flip Vertical	Image is mirrored along the horizontal middle axis.
Crop	A ROI is cut from the image the following way: • Moving the mouse with the pressed left mouse button the ROI is opened in the image, at the same time the **crop**-window displays the according pixel values *start*, *size* and *end* for horizontal (X) und vertical (Y) direction for this region. Following the selected region can be cut from the image by clicking the „*Crop*“.button. • Optionally the desired parameters for the pairs *start, size* or *start, end* (the missing one is automatically calculated) can be typed in and the corresponding ROI is opened in the image. The ROI can then be cropped by clicking the “*Crop”* button.
Resize	Enables the subsequent change of pixel size, in particular the demagnification through a real mean (noise suppression). **Important for Cobalt, Iridium and Selenium exposures:** (see also page 26: EN 14096-2:2002; table 2) *Minimal spatial resolution of X-ray film digitalisation systems:* *from pixel size 50 µm → 100 µm = resize factor 0,5* *from pixel size 50 µm → 150 µm = resize factor 0,333* *from pixel size 50 µm → 40,3 µm = resize factor 1,241* To achieve an optimal signal-to-noise, it makes sense





	to run the scanner only with the resolution supported by the optics (e.g. 50 µm for most laser scanners). Following choosing a resize factor < 1 in this **Resize**-window, the pixel size is enlarged via a real mean. In this way the signal-to-noise increases and the size of the file is reduced.

Image ➔ ***Input Pixel Size and SRb***

Direct Input of the correct pixel size and basic spatial resolution values of the loaded image	An input window for the quadratic pixel size value in **"mm"** is opened and the pixel size of the image and the basic spatial resolution SRb (the read-out value of the unsharpness measured with a duplex wire IQI in accordance with EN 462-5, ISO19232-5 or ASTM E 2002 divided by 2 as effective pixel size of the CR system) can be provided for correct length measurement and normalized SNR measurements. examples: pixel size of 50µm = 0,05mm SRb of 80 µm = 0,08 mm 

Mode menu:



Different analysis modi, which can be activated also by the function keys *(keys F2 to F7)* or by clicking the corresponding icon on the toolbar. In this way 3 different modes are implemented to call the same central program functions for convenience of the user.

Misc menu:

Misc ➔ *Cycle Full Screen Modes*



By subsequent presses of function key F11 ISee! will be displayed in a window on the desktop (default), full size on the display covering the complete desktop or full sized without toolbox on the display. The next press of F11 displays ISee! in a window again.

Misc ➔ *Resize to Half Screen*



example: Resize Half Screen Left and Right

Two ISee! programs will share the screen display side by side in maximum size of the available monitor.



example: Resize Half Screen Top and Bottom



Misc ➔ Resize to Quarter Screen



4 Programs of ISee! started in parallel for image comparison can share the available monitor screen area by adjusting the size automatically to a quarter of the screen for each program.

example: Resize to Quarter Screen in Top-Left, Top-Right, Bottom-Left and Bottom-Right position



Misc ➔ Execute batch

This menu opens a window to select an ASCII text file containing an ISee! batch job. In this way ISee! can carry out batch jobs described by key words and parameters.
The function “Misc -> Log Console” can be used to create a batch job in the windows clip board, which can be save with any text editor to a batch job file.
Please see the external documentation available at the ISee! website http://www.kb.bam.de/~alex/interfacing-with-ic/ for further details in the HOWTO: Interfacing ISee! with external software.
The file containing a batch job can be provided also on the command line at start of ISee!, so ISee! is able to do this ASCII batch job without any user interaction.

Misc ➔ *Remote Controller*

This function realizes the synchronized viewing of 2 or more files (by starting two or more Isee! programs) and communication via telnet connection between these programs (also on different computers via Internet possible*).*

Open ISee > load file No.1
Optimize Image; displayed size like program 2
Call > Misc > Remote controller
Settings for **program 1 (Master)**



Open ISee > load file No. 2
Optimize image; displayed size equal program1
Call > Misc > Remote controller
Settings for **program 2 (Slave)**



Scrolling for both images simulta-nously



Misc ➔ Log Console

This window shows all commands done by user interaction with the mouse in the ISee! program. The Button „mkbatch“ copies this information to the windows clip board for further processing by any text editor to create batch jobs for ISee! to automate (or at least repeat) image processing.



Misc ➔ About

Info on version and availability


About ISee!
BAM
ISee!
v1.10.2
"ISee!" is not yet another image viewer. This program is intended not for quick slide shows or browsing through image directories, but for detailed viewing, careful analysis and documentation of 16-bits grey level images as well as execution of various image-based measurements. Some image processing, digital detector calibration and correction are included to assist this purpose.
"ISee!" is developed by Oleksandr Alexeychuk (oleksandr.alekseychuk@bam.de) in German Federal Institute for Materials Research and Testing (BAM), working group "Digital Radiology and Image Analysis" (http://www.kb.bam.de/dir.html) as the BAM reference software for analysis of radiographic NDT images.
Updates and recent information available at http://www.kb.bam.de/ic.html
ISee! local executions / image loads: 1057 / 1121
OK

The Toolbar of the *ISee!*-window:



	Reload Current Image	By clicking this button the original image is loaded again (e.g. to restart image processing with original data).
	Show Whole Image	Displays the full image in the *ISee*! window.
1:1	Zoom 1:1	Normal view in 1:1 display, i.e. 1 pixel on the monitor is exactly 1 pixel in the data file.
	Zoom in	Enlarges the image with each click of the mouse by a factor of $\sqrt{2}$.
	Zoom out	Minimises the image with each click of the mouse by a factor of $1/\sqrt{2}$.
	Negative Re-presentation	Negative Representation of the image (film like representation of dose proportional data).
	Toggle Latitude Warning	In case the image is saturated, the affected pixels will be high-lighted in the image (blue colour: gray value = 0, red: grey value = 2^{Nbits} -1).
	Toggle Levers Panel	Opens another window - the **Data to screen mapping** -window, in which the gray value display of the image can be modified manually.  For a detailed description of this window see page 22 and 23
	Load Look-Up Table	Loads an LUT which is specific to the scanner, to correct the 16 bit raw data *(see p.4 and 10)*
	Reset Look-Up Table to Linear	Resets the LUT to linear, without changing the original data
	Zooming pan-ning with mouse (F1)	Using the mouse cursor in the image: • with the left button the image can be enlarged • with the right button the image can be shifted • with the middle button the image can be minimised



	Local Histogram Optimization (F2)	Automatically optimisation of the brightness and contrast in a ROI (Region of Interest). When opening the ROI in the image (by moving the mouse with the pressed left mouse button) the histogram in the **Data to screen mapping** -window is automatically optimised. The ROI can be shifted in the image by clicking the right mouse button. *(see also p.22)*
	Profile Explorer (F3)	Measuring the profile along an arbitrary line in the image *(see p. 24)*. *(detailed description see p.24 to 26)*
	Densitometry/ Penetrameter based Thickness Measurement (F4)	For wall thickness analysis (e.g. corrosion pitting), i. e. differences in wall thickness along the direction of X-ray penetration *(detailed description see p.32 to 33)* 
	Local Image Statistics (F5)	Opens another window with the statistics  of the gray values in the considered ROI *(detailed description see p. 28 and 29)*
	Annotations (Rectangular / F6)	Draws a rectangular frame (RO)I in the image and show annotated text. ROI can be rotated too. The„***ROI List"*** manages the annotated text or the size in pixels.  
	Annotations (Circular / F7)	Draws an circular (ROI) in the image. The ***„ROI List"*** manages the annotated text or the diameter of the circle in pixels. 
	Roi List window (**R**egion **o**f **i**nterest)	**Manages the list of annotation data:** Profil plots Penetrameter places Statistics

		Rectangular annotations Circular annotations *(see p. 7)* *(example: „ROI-List“ for profile measurement, see p. 24)* *(example: „ROI-List“ for statistic evaluation, see p. 28 and 29)* 
	Delete or Insert a line into the list	Delete the selected annotation object Add a new annotation object to the list *(see p. 7)*

Description of the *Data to screen mapping levers-window*


ISee! : X:\projects\IAEA\DIR2009\Corrosion\80H20-100_linear.tif (2970 x 3991)
File View Image Mode Misc
ISee! : X:\projects\IAEA\DIR2009\Corrosion\80H20-100_linear.tif (2970 x 3991)
File View Image Mode Misc
20,1% (433,398) GV: 4409 SNR: (55,366)

To optimize brightness and contrast in the display of a digital image (16 bit) on a monitor (8 bit) one uses the histogram. This is the frequency distribution of the gray values in the image. Therefore the histogram in 16 bit resolution gets transformed with the corresponding monitor LUT (look up table), to enable the display on an 8 bit-sized monitor.

.

The **Histogram button**

Opens another window in which the gray scale display of the image can be optimized by sliders for brightness, contrast, gamma etc.

The **Histogram optimization button**

By drawing a ROI (Region of Interest) in the digital image with the left mouse button the histogram will be adjusted automatically according to the gray scale distribution inside this ROI. The pressed right mouse button moves this ROI through the image window. By clicking the ROI edges with the small quadrates with the left mouse button the size of the ROI can be adjusted any time.

Data to screen mapping window

Indicates the dynamic range of the digital image, i.e. the width and position of the current histogram related to the maximum dynamic of 16 bit (gray value of 0...65535).

Scroll bar for gamma setting to compress the image dynamics (via the shown non-linear 8 bit monitor LUT)

Determines **white** value for monitor display

current 8 bit LUT for image display

Determines black value for monitor display



Selection mark of parameters for 16 → 8 bit transformation of the current 8 bit monitor LUT

Indication of parameters for the selection mark of the current 8 bit monitor LUT:

Gray value of the histogram slot

Number of pixels in the histogram slot

Region of gray values for display on the monitor after 8 bit monitor LUT-transformation

☑ log histogram	Semi-logarithmic plot of the gray value histogram, if checked.
☐ latitude warning	In case of image saturation the highlighting of the affected pixels can be switched on/off (blue: gray value = 0; red: grey value = 2^{Nbits} -1).
☐ negative	Enforces the display of the negative image; the shown monitor-LUT will be inverted, but denoted unchanged in the window.
Optimize View	Optimises the LUT in the currently shown region of the image in the *ISee!*-window.
Optimize Full	Optimises the monitor-LUT for a display based on the histogram over the entire image.
Reset	Resets the monitor-LUT for the image back to the starting value (display width Nbit).

Description of the *"Profiler"* window

By clicking the button for profile measurements the ***Profiler window*** is opened. This window presents all information on the selected profile and the measurement values too.
With the left mouse button the profile is drawn (simultaneously pressing the Ctrl-key on the keyboard restricts the profile direction to vertically or horizontally only*).*
With the pressed right mouse button the profile position in the image can be moved.



***Profiler* window:**
In this window the gray values are displayed graphically along the selected line in the image. Length, position and width of the profile can be chosen arbitrarily.
After pixel size calibration the X axis is displayed in "mm", otherwise in pixels.

By clicking two times at the profile plot two cursors can be activated and controlled with the mouse. In this way exact profile measurements can be done.

The activated OSD field (on screen display) displays the distance of the two cursor positions along the profile in the image (e.g. for visual wall thickness verification)

The cursor positions can be moved by mouse along the profile. Here they are placed at the inner and outer wall in a tangential shot through a steel pipe.



green cursor mark = **start**
(click left mouse button)
blue cursor mark = **end**
(click left mouse button)
(the right mouse button moves both cursor marks together along the profile)

black values = current cursor position
green values = start pos. [mm : gv]
blue values = end pos. [mm : gv]
red values = difference [mm : gv]


min: 22550 max: 48279 median: 47756 mean: 46204 std: 4519
7,63 : 47781 8,29 : 34117 0,653 : 13664 n/a OSD
Start (x,y): 5334 4966 End (x,y): 5767 5007 Width: 22 Sampling:
Smooth: 1 1st Derivative Spectrum Magnitude Log Y Mem Recall
Calibrate Pixel Size Plot: zero-order 22550 48279 Save
manual measurements
manual measurements
outer diameter (outer-outer walls)
inner diameter (pipe inner-inner walls)
wall thickness (pipe inner-outer walls)

Start (x y):	Coordinates of the start position of the marked line (profile center line) in the digital image
End (x y):	Coordinates of the end position of the marked line (profile center line) in the digital image
Width:	Width of the profile. Equal to the number of neighbouring profiles over which the mean is calculated perpendicular to the centre line of the profile (to suppress noise).
Mem	Saves the data of the profile setup in the registry of the computer.
Recall	In case of restarting the program or clicking of this button the saved data will be re-read from the registry.
Smooth	Number of points for smoothing along the line of the profile. ***WARNING: values bigger than 1 round of the edges of the profile!***
1 st Derivative	Calculates the first derivative of the chosen profile by displaying the difference between neighboured pixels.
Spectrum Magnitude	Calculates a 1dim real FFT of the chosen profile. Usefully for MTF calculations from line or edge responses, detection of artefact frequencies or measurements of focal spots.
Log y	Semi-logarithmic plot of the profile.
Calibrate Pixel Size	The **Calibrate Pixel Size button** allows the geometrical calibration of the image by pixel size determination. There are two possibilities: 1. With a known length in the image the Pixel Size Calibrator calculated the exact pixel size from the profile cursor positions and the given length example*:* distance *10mm* cursors on profile peaks ***calculated pixel size*** 2. With a known pixel size a direct pixel size input is possible in the window Pixel Size Direct Input (in **„mm“)** and confirmation with Done. (This is only possible after closure of the window *„Pixel Size Calibrator“)* *examples:* ***50µm*** *scan resolution* ***Pixel Size = 0,05mm****;* ***100µm*** *scan resolution* ***Pixel Size = 0,1mm*** *The X axis of the profile plot is shown in mm.*




Pixel Size Direct Input
Pixel size: 0,0794 mm Done
Pixel Size Calibrator
Please lay a profile over an object of known size, mark this object in the profiler window and enter its size in the field below. Thereby the effective pixelsize will be calculated (for the particular setup) and used for the subsequent image evaluation (direct input of pixelsize is disabled until the calibration is finished)
mm Finish Calibration



min:	Minimum gray value in the profile *(min. value: 18970)*
max:	Maximum gray value in the profile *(max. value: 48234)*
median:	Median gray value – the middle gray value after sorting of gray values according to their values *(median value: 47736)*
mean:	Mean value of gray values *(mean value: 45947)*
std:	Standard deviation of gray values in profile *(standard deviation std: 5141)*

Cursor Pos.	Current mouse position [mm] and gray value at the displayed profile. *(12,4 : 45770)*
Pos. green	Position [mm] and gray value [gv] of the green cursor *(8,61 : 447802)*
Pos. blue	Position [mm] and gray value [gv] of the blue cursor *(9,31 : 35574)*
Red values	Difference of the positions and gray values of both cursors *(0,705 : 12227)* The value in % *(83,4 %)* is calculated for the profile value at mouse position using both cursors to mark the 0% and 100% position on the profile. This is very usefully for the evaluation of the dip depth at duplex wire images.
OSD	On Screen Display: activated the profile cursor positions are displayed in the image too, the distance in pixels or mm (only after image calibration) is shown.

Plot	**first –order**: (default) construction of profile by lines connection the pixel gray values **zero-order:** construction of the profile by steps with the pixel width (physical profile presentation)
Y-scaling	To magnify the profile plot in gray scale direction the min. gray scale (18970) and the maximum gray scale value displayed in the profile (48234) can be corrected manu-ally here. A shift in theprofile plot position will overwrite these values by new ones.
Save	The full profile is saved, i.e. each point of the profile, consisting of x- and y-value for each row, is saved in an ASCII-text-file (*.txt). The decimal point is chosen specificly to the country set-up of Windows (German: "**,**" and English: "**.**")
Manual measure-ments	The two cursor positions (green and blue cursor, see above) are set interactively with mouse clicks by default. But there are 3 other simple automated positioning tools for measurements available: **outer diameter (outer-outer walls)** for automatic measurements of outer object dimensions (for pipes, wires and other objects with clear outer edges) **inner diameter (pipe inner-inner walls)** for automatic measurements of inner object dimensions (e.g. bore hole of pipes or inner dimensions of other cavities) **wall thickness (pipe inner-outer walls)** for measurement in projection radiography of pipes to estimate the remaining wall thickness in tangential pipe direction

Example of generation and storage of profile plots:

The selection window **ROI** has to be opened and the profiler selected too.



1. Draw the first profile position in the image, the profile selector generates automatically an **ID Roi 1**. In the field **Description** some description can be placed, e.g. ***Stufe 1***. The difference of the cursor positions will be shown at the column **Value** (***2,62mm)***
2. The button +R generates another profile raw in the list. A new **ID** **Roi 2** is generated.
   Draw the second profile with the mouse on the image, provide a description, e.g. ***Stufe 2,*** in the field **Discription**. The cursor position difference will be transferred to the column **Value** of the raw **Roi 2** (***3,26mm).***
3. This can be repeated up to 50 profiles.
4. The button -R allows to delete selected lines in the list.

Storage and loading of dataset files

The data of several profiles at different positions can be stored in the same **ISee-dataset-file (*.ics)**. Storage takes place by clicking the following buttons in the main window:



File ➔ ***Save Dataset As…***

.



In the ***.ics** ASCII file all information is stored. This enables the later replication of the analysis by simply loading this ***.ics-file** in the following way:



With ***File*** ➔ ***Open*** (also for data sets!) or
File ➔ ***Open Recent Dataset or Image***
(a list with the last 12 loaded data sets is shown)
The saved ***.ics** dataset files can be retrieved and all objects in the list are shown again.

Description of the window "Statistics in window"

In this window the noise in the digital image as well as the signal-to-noise ratio can be determined and saved in an ASCII file table.

- Using the left mouse button (keep pressed and move mouse) a ROI can be opened in the image, at the same time the *Statistics-window* displays the pixel-values for ***start***, ***size*** and ***end*** in horizontal and vertical direction for the according ROI.
- Optionally one can type in the ***start*** and ***size*** values in the *Statistics*-window to open a ROI of the desired size.
- With the pressed right mouse button at the ROI border it can also be shifted in the image at any time and position.
- To resize the ROI one grabs one of the small squares in the corners of the ROI and moves the mouse with the pressed left mouse button to the desired ROI size.
- The statistical analysis is then carried out on the data obtained *after* the 16 bit LUT-transformation.



ROI number of pixel in the selected ROI

Indication of parameters for the entire ROI area:

horizontal start size end	Horizontal position of ROI window Start pixel number window width in pixel End pixel number
vertical start size end	Vertical position of ROI window Start pixel number window height in pixel End pixel number
sample in windows	Number of pixels in the area of ROI



min	Minimal gray value
median	Median gray value
max	Maximum gray value
mean	Mean value of all gray values
stdev	Standard deviation of the mean value
mean/stdev	Ratio of both values, normally the signal-to-noise-ratio in the ROI

Analysis of the ROI per line:



median single line mean:	Median of all mean values per line, which are sorted according to their size.
median single line stdev:	Median of all standard deviations per line, which are sorted according to their size.
unnomralized SNR:	Ration of Median single line mean / median single line stdev
basic spatial resolution:	Input window for the value of the basic spatial resolution in the image data (see EN 14784-1 for details).
Normalized SNR:	Ratio of Median single line mean / median single line stdev, multiplied with 0,0886mm/BSR.



...	To choose a directory in which the statistical data will be saved as an ASCII-file (*.txt).
Mem	Saves the set-up data of the *statistics-window* for the according position of the ROI in the registry of the PC..
Recall	In case of restarting the program or clicking this button, the data for the ROI´s position will be re-read from the registry; size as well as position of the ROI will then be accordingly set.
Record	A new line with the current statistic data of the window is added to the selected ASCII-file. The successful writing of the data is confirmed by a short beep. This way step wedges can be easily measured by simply moving the ROI.

Generation and storage of several statistic windows with the help of a ROI list window



Usefully for evaluation of several similar images, e.g. step exposures.

Open ***ROI List*** via menu ***View*** ➔ ***ROI List*** or press button in the toolbar, an empty *ROI list* is generated.

Example:

Measurement of the linearized signal intensity $\mathbf{I_{meas}}$ (the median value in the statistics window) and the normalized signal-to-noise-ratio SNR_N (a correct input of the basic spatial resolution value in the image is required!)



1. Add 7 ROIs in the middle of each of the steps to be measured. (Optimal ROI size **20x200 pixel**, see EN 14784-1), save the complete set-up with ***Save Dataset as*** under the name e.g. „***7 Roi_Fastscan-Richtung.ics***“

2. Open with any text editor this file **„7Roi_Fastscan-Richtung.ics“**. Replace in line starting with **image=** path and **file name** by the new file to be evaluated. Save this under a suitable file name.

   Open this new data set file with Isee! and the new image data are evaluated exactly at the positions as the file before. Replace this data set file by **save data se**t to correct all measurement data in this file with the data generated from the new image.
   This procedure can be repeated until all files are evaluated accordingly.



Advantage:

All data files are evaluated exactly at the same positions and no manual input of ROI positions is required.

3. To measure the linearized signal intensity $\mathbf{I_{meas}}$ (in statistics window the medien value) and the normalized signal-to-noise-ratio SNR_N (last value in statistics window) the display of the step to be measured should be optimized before via Zoom In and contrast optimization . The measurement ROI should be placed in the middle of the step, without shading or artefacts.. By clicking on each line in the Roi list all values in the statistics window are updated. The

current ROI data set can be appended to a *.txt file with the **Record** button in the statistics window. This file can be selected with the button ... *Select file for statistic* in recording.

Important!
The name of this file should be equal to the name of the image file analysed for simple connection between image data and measurement results!



Description of the *Penetrameter*-Window

The Penetrameter-window allows for 2 working modi:

1. Mode: µ-estimation

This mode enables the determination of the effective absorption coefficient from known wall thickness differences. For an accurate determination the correct linearization of the detector characteristics is essential, i.e. the gray value after carrying out the LUT linearization has to be directly proportional to the intensity of the detector! There is since version 1.7 of Isee! one LUT only (which is shown at the status line of the ISee! window)!

Recommended LUT for scanner Vidar VXR-16 and X-ray films from non-destructive testing:

LUT16bitlog-fog.txt
(i.e. CCD signal is proportional to luminance. The logarithm gives the film density, an overlay on the film of D=0.2 is subtracted as an offset, the film density is proportional to the intensity for all films in non-destructive testing for D<5 with deviation smaller then 10%.

A point of reference for pure absorption is: μ_{eff} =0.072 1/mm for Ir-192 as radiation source. Taking into account scattering the typical μ_{eff} –value can deviate from this point of reference to smaller values; it is dependent on the particular radiographic energy, object material and set-up.

The wall thickness in any case has to be taken as the value of the entire penetrated wall thickness in the direction of radiation.

Pitting evaluation

1. Calibration (µ-eff estimation)

test pipe DN 200 x 8,45 mm
Co-60

known wall thickness
at measurement point

known wall thickness
at reference point



2. Mode (µ-estimation mode inactive): measurement mode

This mode is the real measurement mode in the *Penetrameter* window. Two parameters need to be given to carry out a successful measurement:

1. The value of the penetrated wall thickness at the reference point (e.g. twice the given wall thickness of the pipe at an un-corroded area on the symmetry axis of the measuring point) and
2. The locally valid value of μ_{eff} for the image which is to be analysed. This can either be determined in the *µ-estimation mode*, given a known wall thickness differences or it can be taken from analogous images with the same geometrical set-up and identical radiation source, detector array and pipe geometry.

.

Pitting evaluation

2. depth measurement

pitting depth: 3mm

µ-eff = 0,029 +/- 0,002 mm
as measured in step 1

known wall thickness
at reference point

Result: local penetrated wall thickness in mm
(error ca. 0,2 mm)



The result is the penetrated wall thickness at the measuring point. Normally the corrosion depth is calculated via the difference of the latter and twice the single pipe wall thickness, because the indication of the corrosion is located only at one side of the double-wall radiograph. From the projected image it is not possible to decide whether the indication of the corrosion is on the tube side facing the film or on the one, which is located opposite to the film. The *penetrameter* window shows also the errors for the particular measured values based on the error propagation law and the image noise. In this way it is possible to derive from the uncertainty of the attenuation coefficient µ-eff the influence on the error of the wall thickness measurement.

Examples for measurements of lengths in images:

1. Load image file
2. Locate the object: (IQI)

   Zoom 1:1
3. Open profile window
4. Calibrate Pixel Size of the scan
   e.g.: 50 µm = 0,05 mm
5. Click on start of profile (green mark)
   (click **l**eft **M**ouse button)
6. Click on end of profile (blue mark)
   (click **l**eft **M**ouse button.)
7. With of the IQI is displayed, the value is
   15.0 mm



Examples of filtering digital images:

ⓘ **Information:**
In processing digital images the "Minimum spatial resolution of film digitisation systems", EN / ISO 14096-2, table 2, has to be considered if analysing digital films..

Filtering of a digitized radiograph of an X-ray exposure:

X-ray exposures of ignition fuses:
(scan of 50 µm pixel size; 12 bit)

1. Load original image *(chose according scanner-dependent LUT).*
2. Use **Crop** to trim the original image.
3. Use **Zoom** to enlarge the area.
4. Use **High-boost**-filter to sharpen the image (**x = 200%)**.
5. Finally save under a different file name.

1. Original image | **2. Crop** | **3. Zoom** (here 34,2%) | **4. High-boost** (for the entire image)



Filtering of an Ir-192 radiograph of a bronze statue

Enhance Details und Extract Details:

These are 2 dimensional FFT highpass filters without any parameter.
They are optimal for suppression of strong background signals and enhancement of fine details.
Extract details filters stronger than **Enhance details**.

Original image:



Filter result of **Enhance Details:**



Filter result of **Extract Details:**



Filtering of an X-ray image with big differences in gray values

X-ray exposure of a ceramics tube pb147 (Scan of 50 µm pixel size; 12 bit)**:**

1. Load original image *(chose according scanner-dependent LUT)* and use **Crop** to trim the original image to the size of the tube diameter.
2. Using the **histogram display** to optimise the brightness and contrast of each defect separately on the monitor.
3. **High pass**-filtering to achieve a better detection of the defects.
4. Finally save under a different file name.

1. Original image of the ceramics tube ***Defects are hardly visible on the monitor, because the gray value differences are very big.***	
2. Histogram display optimised on defect 1 (pore) **Defect 1 hardly detectable**	
3. Histogram display optimised on defect 2 **Defect 2 detectable**	
4. High pass-filtering (with gray value offset)*:* Suppression of low frequency background, as a result the image becomes noisier, but the edges are displayed well. *Chose filter size as big as possible* *Gray value offset (gv-offset) approx. half of the maximum bit-region* **Rec. window 51 x 51 pixel** ***gv-offset* (for 12 bit): 2000** **Defect 1 and 2 well detectable**	

Filtering an image of a cobalt exposure *(Beispiel-Filter-Co-60*.tif)*:
(Scan of 50 µm pixel size; 12 bit)

1. Load original image (chose according scanner-dependent LUT).
2. Low-pass filtering with 2N-1 points (**5 x 5** points), Anti-Alias filter!
3. Modification of resolution/pixel (sub sampling) of N=3 points.
   Cobalt exposure with a scanner resolution of **50 µm** → **150 µm** resolution
   subsample with **rezise factor (0,333)**
4. High-pass filtering (**31 x 31** points / **gv offset = 2000**),
   or
5. Pseudoplast filtering **(x=3; y=3; gv offset = 2000)**.
6. Finally save under a different file name.

1. Original image


2. Low-pass


3. Resize


4. High-pass


5. Pseudoplast


Filtering an iridium exposure of a bronze statue pb122 *(Beispiel-Filter-IR-192*.tif)*:
(30 x 40 cm film; scan of 100 µm pixel size; 12 bit)

1. Load original image and trim image using **Crop**.
2. **High-boost filter** for sharpening of the image (**x%.= 200**)
3. **Pseudoplast filtering (x = 3; y = 3; gv offset = 2000)**
4. **Band pass filtering** =
   Low-pass filtering (**5 x 5** points) + high-pass filtering (**31 x 31** points **/ gv 2000)**
5. Finally save under a different file name

1. Original image - Crop



2. High-boost filter



3. Pseudoplast filter



4. Band pass filtering



Information! ***In processing digital images table 2 has to be beared in!***

Appendix: Abstract from EN / ISO 14096-2:

Minimum requirements for film digitalisation quality classes

Density range and working ranges of the film digitalisation

Table 1 defines the minimum density range of the radiographic digitalisation system. In this density range the digitiser shall provide a density contrast sensitivity ΔD_{CS} von $\Delta D_{CS} \leq 0{,}02$. Depending on the construction of the digitiser, this density range can be split into several working ranges.
The minimum digital resolution is given for devices converting the digital value proportional to the optical density. If the digital value is converted proportional to the light intensity, the digital resolution has to be increased at least by 2 additional bits.

Table 1 — Minimum density range of the radiographic digitisation system with a minimum density contrast sensitivity

Parameter	Class DS	Class DB	Class DA
Density range[a] D_R	0,5 bis 4,5	0,5 bis 4,0	0,5 bis 3,5
Digital resolution [bit]	≥ 12	≥ 10	≥ 10
Density contrast sensitivity ΔD_{CS} within D_R	≤ 0,02	≤ 0,02	≤ 0,02
[a] This density range may be splitted into separated working ranges.			

Minimum spatial resolution of film digitisation

Due to the energy dependence of the inherent unsharpness of industrial X-ray film systems the following parameters (table 2) shall be observed:

table 2

Energy	Class DS		Class DB		Class DA	
KeV	**Pixel size µm**	MTF 20 % lp/mm	**Pixel size µm**	MTF 20 % lp/mm	Pixel size µm	MTF 20 % lp/mm
≤ 100	**15**	16,7	**50**	5	70	3,6
> 100 to 200	**30**	8,3	**70**	3,6	85	3
> 200 to 450, Se-75, Yb-169	**60**	4,2	**85**	3	100	2,5
Ir-192	**100**	2,5	**125**	2	150	1,7
Co-60, > 1 MeV	**200**	1,25	**250**	1	250	1

NOTE 1 For the normal check corresponding to EN/ISO 14096-1, the MTF-20% value may be determined by the converging spatial resolution targets.

NOTE 2 Due to the possible aliasing, the converging spatial resolution targets may give less accurate values than MTF measurement.

NOTE 3 For energies lower than 70 keV the spatial resolution of the radiographic film can be better than the scanner resolution required by the DS 16 scanning class. In this case the spatial resolution of the scanner should be adapted to the film resolution, or the original radiographic film should be archived.